


0000E0000000000000000000



F16. 1




FIG. 2




FIG. 3

SELECTION OF A SET OF COMMANDS  
TO USE ON THE SAF-TE ENCLOSURE




FIG. 4

REQ. DEVICE SLOT CHANGED STATUS (OR READ  
ENCLOSURE CHANGED STATUS) COMMAND OPERATION




FIG. 5A

READ DEVICE SLOT CHANGED STATUS (OR READ  
ENCLOSURE CHANGED STATUS) COMMAND OPERATION  
(CONTINUED)




FIG. 5B